


Plug-in Linear Light Installation Manual

Step 1


Take out the lamp and inspect the product condition, especially for the lens and plugs , any broken product can not be working or installed.

Warning : Make sure the power is off before installation.



Step 2

Check the exiting rails and unfolded the **plug** and the **safe clips** of both side




Step 2




Step 3

Check the **safe clips** , confirm the width of the safe clips , choose the suitable one if necessary based on the inside width of the exiting rail.




Step 3




Step 4

Insert the **safe clips** to fasten the lamp on the exiting rails.




Step 5

Connect the **feed-in plug** with the **input power plug**




Step 6

Press the **Auto-Reset clips** and lift up insert into the exiting rails to finish the installation




RIDI Rail+Plug-in Linear Light

Philipps Rail+Plug-in Linear Light



TRILUX Rail+Plug-in Linear Light



Different brand of Trunking Rail+Plug-in Linear Light

All the measurement size is based on the general data from different companies , the real size may be with difference